

Revvo Gateway Installation Guide

Step #1

- Open the cuphold flap on the left side of the driver's footwell.
- Open the OBD trim panel above the parking brake pedal.
- Pass the OBD cable (OBD plug first) through the opening and route behind trim to OBD port and plug into the OBD port.



Step #2

- Use alcohol wip to clean surface on top of the steering column
- Peel back the adhesive backing on the GPS Antenna.
- Place GPS antenna on top of the steering column - cable pointing to the left.
- Route GPS cable behind steering column.
- Pass GPS plug to cupholder panel opening.



Step #3

- Route the power cable and the GPS antenna cable behind the trim and to the opening of the cupholder panel. (If applicable)
- Plug both cables into their respective ports on the Rev



Step #4

- Peel off the adhesive backing on the underside of the Revvo gateway and stick the gateway to the left-hand side wall of the vehicle with the cables facing the cabin.
- Close the cupholder trim and OBD port panel to complete the installation.

